

BIJLAGE

* **LOV uitvoering**

De omvormers uit de IPC- en PB- serie kunnen worden afgeregeld zodat ze te gebruiken zijn als laadomvormer (LOV types). De uitgangsspanning is dan aangepast naar een hoger voltage, nl. 14,2Vdc of 28,4Vdc. De LED's hebben hierbij een andere betekenis:

Power on:	accu aangesloten op uitgang
Battery low:	ingangsspanning te laag
Overload:	maximale belasting op de uitgang aanwezig. Bij een ontladen of zwaar belaste accu zal deze altijd oplichten.

***Maak bij een LOV altijd gebruik van de D+ kabel!
Zie handleiding.***

* **SP uitvoering**

Indien aan het artikelnr. de letters SP zijn toegevoegd betekent dit dat de omvormer op klantspecificatie is aangepast. Dit kan o.a. de uitgangsstroom of uitgangsvoltage betreffen. Hierdoor kunnen de technische specificaties afwijken van die vermeld in de gebruiksaanwijzing.

BIJLAGE

* **LOV uitvoering**

De omvormers uit de IPC- en PB- serie kunnen worden afgeregeld zodat ze te gebruiken zijn als laadomvormer (LOV types). De uitgangsspanning is dan aangepast naar een hoger voltage, nl. 14,2Vdc of 28,4Vdc. De LED's hebben hierbij een andere betekenis:

Power on:	accu aangesloten op uitgang
Battery low:	ingangsspanning te laag
Overload:	maximale belasting op de uitgang aanwezig. Bij een ontladen of zwaar belaste accu zal deze altijd oplichten.

***Maak bij een LOV altijd gebruik van de D+ kabel!
Zie handleiding.***

* **SP uitvoering**

Indien aan het artikelnr. de letters SP zijn toegevoegd betekent dit dat de omvormer op klantspecificatie is aangepast. Dit kan o.a. de uitgangsstroom of uitgangsvoltage betreffen. Hierdoor kunnen de technische specificaties afwijken van die vermeld in de gebruiksaanwijzing.

ENCLOSURE

* **LOV models**

The converters from the IPC- and BP series can be adjusted so that they can be used as charge converter (LOV types). The output is adjusted to a higher voltage, namely 14,2Vdc / 28,4Vdc. The LED's meaning will change:

Power on:	battery connected to output
Battery low:	input voltage to low
Overload:	maximum load present on the output. This LED will always burn at a discharged or heavily loaded battery.

***In case of a LOV, always use the D+ cable!
See manual.***

* **SP models**

When the letters SP are added to the article number it means that the converter is modified to customers specification. This concerns among others the output voltage or output current. In this case the technical specifications deviate from the those in the manual.

ENCLOSURE

* **LOV models**

The converters from the IPC- and BP series can be adjusted so that they can be used as charge converter (LOV types). The output is adjusted to a higher voltage, namely 14,2Vdc / 28,4Vdc. The LED's meaning will change:

Power on:	battery connected to output
Battery low:	input voltage to low
Overload:	maximum load present on the output. This LED will always burn at a discharged or heavily loaded battery.

In case of a LOV, always use the D+ cable! See manual.

* **SP models**

When the letters SP are added to the article number it means that the converter is modified to customers specification. This concerns among others the output voltage or output current. In this case the technical specifications deviate from the those in the manual.